Preparation

1 | UNFOLD

Remove Signus from its trolley and unfold the frame.



4 | ANCHORING

First anchor the leg that is facing the wind.






2 | POSITIONING Make sure all the valves are facing upwards.



5 | CLOTHS
Use the inner zipper for water repellent cloths.
Use the outer zipper

for printed cloths.

3 | TIGHTEN VALVES Each segment has 1 inflate / deflate valve and 1 overpressure valve. Tighten the valves



6 | ATTACH CLOTHS Start with connecting the zippers at the top then connect the sides



ZIPPERS





Inflate

7 | INFLATE ROOF Plug the electrical pump firmly in

Plug the electrical pump firmly in one of the open valves. Inflate the 3 roof segments one by one.



ABOUT THE PRESSURE

Inflate untill the tube feels very solid (3PSI/0.2 BAR).
The remaining air will escape through the overpressure valve.











8 | INFLATE LEGS Plug the electrical pump firmly into one of the open valves. Inflate the 3 leg segments one by one.













9 | POSITIONING LEGS Push the 3 legs about 1 feet (30cm) to the centre of the Signus for a symmetric shape. Anchor the remaining legs.







10 | ANCHORING Allways anchor the tent by using the 2 remaining anchorpoints. Place the pegs deeply into the ground and under an angle of 40 degrees.








10 | DEFLATE

Deflate Signus by opening the six inflation valves. Do not remove the overpressure valves.



12 | STORAGE

Do not storage the Signus when it's wet. Hang both frame and cloths in a dry environment.





Do not use sharp objects



Do not use chemicals for cleaning



Do not use near an open fire or heated objects



Do not store the Signus when it's wet



11 | FOLD

Can be used till 6 bft.



Pressure (3PSI/0.2 BAR)



Anchor with pegs on soft ground



Anchor with concrete blocks on hard ground

Tube

NEVER LEAVE THE SIGNUS UNATTENDED AND TAKE CARE OF YOUR BELONGINGS

AFTER USE OF THE SIGNUS ONE STORE IT IN A DRY PLACE

Never store a wet tent. Hang out all the cloths and the tube in a dry and warm place.

CLEANING

Only use water with a soft handbrush and a wet cloth to clean the tent. Do not use any cleaning products.

White clothes 3 x



Custom clothes 3 x





Inflate / Deflate Valves 6x + 2 spare valves



Overpressure valves 6x + 2 spare valves



Knee caps





Roof center cover



Accessory bag



Electrical pump



Hand pump



Blue screw pegs





3 x



